

E300N / E300NT / E300B / E300N2 / E300NT2



1	Z32CNM	E300N assembled top-shell black
	Z32CBM	E300B assembled top-shell white
	Z32CNTM	E300 Tech assembled top-shell black
2	Z29FNM	E280 - E300N - E300B bottom-shell black
	Z2900FNM	E300N2 bottom shell
	Z2900FNTM	E300NT2 bottom shell
3	Z1732SR	Central reflector for E300N, E300N2
	Z1732FSR	Central reflector smoked for E300B, E300 TECH, E300NT2
4	Z314NM	Hinge stop for E300N
	Z2901NM	Hinge stop (for E300N2)
	Z2901NTM	Hinge stop (for E300NT2)
5	Z140R	Key locks with corresponding bush with red handle
6	Z310	Bolt for E300N / E300NT / E300B

	Z762NR	Bolt, 1 pcs. for E300N2 / E300NT2
7	Z112R	Red pulley, 4 pcs.
8	Z115R	Stop bag opening yarn, 2 pcs.
9	Z193	Hinge pin 62 mm
10	Z191R	Push button spring, 1 pcs.
11	Z315	Push button for E300N
	Z315NR	Push button silver for E300NT / E300B
	Z645R	Push button red for E300N2
15	Z243	Key lock plate for E300N / E300NT
	Z4513R	Plate below lock for Security Lock key
	Z640R	Plate below lock for standard key for E300N2 / E300NT2
16	Z2000R	Chromed GIVI logo